



Post-processing in paraFoam

Håkan Nilsson, Chalmers / Applied Mechanics / Fluid Dynamics



Post-processing in paraFoam

- paraFoam is the main post-processor distributed with OpenFOAM. As previously mentioned, you can also use other alternatives. However, paraFoam is quite powerful and competitive with commercial alternatives, and it is based on OpenSource software.
- paraFoam is a wrapper for the third-party product Paraview (www.paraview.org). It basically generates a file named <case>.OpenFOAM, which is necessary since Paraview needs a file to be specified. paraFoam also makes sure that the OpenFOAM reader is used, and that the paraview GUI is modified according to the specifications for OpenFOAM.
- Paraview is based on VTK, the visualization toolkit (www.vtk.org)
- Results from OpenFOAM can be converted to the VTK format using foamToVTK. In some cases, like for lagrangian particle tracking, this may in fact be necessary.
- References: The ParaView Guide, ISBN 1-930934-21-1, VTK User's Guide, ISBN 1-930934-13-0, The Visualization Toolkit, ISBN 1-930934-12-2, Programming Python, ISBN 0-596-00085-5.



Post-processing the icoFoam/cavity case in paraFoam

In the following, we will use paraview and the OpenFOAM reader compiled with OpenFOAM. It looks slightly different if you use the OpenFOAM reader that comes with Paraview.

- We will now do some post-processing of the icoFoam/cavity case, with the purpose of learning the basics of Paraview.
- Go to the icoFoam/cavity case that we have already run: cd \$FOAM_RUN/cavity
- Type paraFoam& to post-process that case.
- The case name will appear as the object cavity.OpenFOAM in the Pipeline Browser.
- If you do an ls -l in the case directory you will see that a temporary empty file named cavity.OpenFOAM has been generated.
- The object can be controlled using the Object Inspector, which we will discuss in the coming slides...



Object Inspector / Properties tag

- In Mesh Parts, check what parts of the mesh should be imported.
- In Volume Fields, check what volume fields should be imported.
- Click on Patch Names if you want to view them. Then you also need to tick the patches in the Mesh Parts.
- Click on Include Sets and/or Include Zones if you have sets or zones that you want to visualize. This is very useful in order to check if your sets and zones have been generated properly. However, in the cavity case, we have no sets or zones.
- Click Apply to read in the mesh and the volume fields.
- If the contents of your case directory has changed, click on Update GUI and Apply to import the new information. Since 2.0.x and Paraview 3.10.1 there is also a Refresh Times button and a Skip Zero Time tick-box (since the zero directory may in some cases be incomplete, from a paraFoam point of view - not from an OpenFOAM point of view).



Object Inspector / Display tag

- Control visibility (can also be done by clicking on the 'eye' in the Pipeline Browser).
- Color the object by a Solid Color, or using a variable. For cell based representation (box), the variables are assumed to constant in each cell, and for point based representation (point), the variables are interpolated to the points, yielding a smooth field. The colormap can be edited, and the color range can be re-scaled. In Edit Colormap, a Color Legend can be added (also using icons Edit Colormap and Toggle Color Legend Visibility). The color legend can be moved and re-scaled with the mouse.
- The representation of the object can be as outline, wireframe, surface etc.
- The cartesian extent of the object is shown by clicking on Show cube axes. This representation can be edited. This is great to check that your geometry was generated in meters!
- The object can be translated, scaled and rotated, which is useful when comparing results from different simulations of the same case, or when viewing the same case in different angles.



Object Inspector / Information tag

• Here you get some information on the mesh and the fields.

Håkan Nilsson, Chalmers / Applied Mechanics / Fluid Dynamics





Visualization window

- Rotate by holding the left mouse key, and moving the mouse. It is like rolling a ball.
- Zoom by holding the right mouse key, and moving the mouse up and down.
- Move by holding the center mouse key, and moving the mouse.



Visualization window

• At the top left of the visualization window, you can see five icons:

(actually only four in newer Paraview versions)

- No1: Undo last visualization transformation.
- No2: Redo last undone visualization transformation.
- No3: Edit View Options (background color, parallel projection, lights, toggle Orientation Axes - if 'interactive', you can move them with the mouse, toggle Show Axes of center of rotation - can also be done using icon Show Orientation Axes).
- No4: NOT IN 3.8.0, INSTEAD YOU CAN DEFINE FOUR CAM-ERA VIEWS IN THE LAST ICON! (Before: Lookmark (if you want to save a view))
- No5: Adjust Camera (use standard views, or adjust the views).



Visualization window

- At the top right of the visualization window, you can see four icons:
 - No1: Split Horizontal.
 - No2: Split Vertical.
 - No3: Maximize (only useful if there are multiple visualization windows).
 - No4: Close (only useful if there are multiple visualization windows).



Filters

• The Filters/Alphabetical menu lets you manage your data in different ways. Some of those can be selected by the icons:



• We will have a look at some of them in the next slides...



Calculator Filter

- With the Calculator filter you can create new fields from existing scalar and vector fields, using simple mathematical functions.
- The new fields can be used just like the original fields.
- Create a new scalar field that is only the X-component of the velocity by clicking on Scalars and choosing U_X. Specify Result Array Name as for instance U_X, and click Apply. A Calculator1 object appears in the Pipeline Browser, and the geometry is colored by U_X. The new object is based on the object that was selected when generating calculator1.
- Use the 'eye' icon in front of the objects to show/hide each object.
- The cavity.OpenFOAM object can in fact directly be colored by U_X by choosing U and X.
- Delete the calculator1 object by clicking on it in the PipelineBrowser and then clicking on delete in Object Inspector/Properties.



Contour, Clip and Slice Filters

- The Contour Filter lets you make a contour plot or iso-surface, if the parent object is 2D or 3D, respectively. A value range can be specified for several values at the same time. Make sure not to be in the 0 time!
- The Clip Filter W lets you clip your results using plane/box/sphere/scalar.
- The Slice Filter lets you make plane/box/sphere cuts through your results.
 - It is possible to specify the plane in different ways.
 - Multiple cuts can be made simultaneously using Slice Offset Values.
 - Each Slice will generate a new object in the Pipeline Browser, which can be colored etc. like any other object.



Threshold, Glyph and Cell Center Filters

- The Threshold Filter is lets you show cells with solution scalar values in a specific range.
- The Glyph Filter lets you make vector plots. It can also be used to visualize lagrangian particles.
 - Glyphs are by default generated at the grid points. If you want the vectors to be located in the center of the cells, you first need to make a new object of the cell centers using the Cell Centers filter that can be found in Filters/Alphabetical.
 - Mark the cell centered object, and filter it with the default values of the Glyph Filter.
 - It is possible to modify the representation of the vectors in the Properties tag.



Stream Tracer and Warp Filters

- The Stream Tracer filter ilets you make streamline tracers, submitted from a point, a spherical cloud, or line sources.
- The Warp By Vector filter lets you distort your geometry according to the local value of a vector. This is mostly useful in solid mechanics. There is also a Warp By Scalar filter available in Filters / Alphabetical, where you can find many additional filters...



Plot Over Line Filter

- In Filters / Alphabetical, you find a long list of filters.
- The Plot Over Line filter lets you make detailed plots of the variables along a line.
- In the Display tab, you can choose which variables to plot, and choose line colors and line styles.
- Later on we will learn how to extract line data using the OpenFOAM sample utility, and plot it in OpenSource Gnuplot, www.gnuplot.info, (or any other plotter).



Image output

- File/Save Screenshot saves pixel images in a number of formats: png, bmp, tiff, ppm, jpg, pdf
- The format is chosen by the extension of the filename.
- Increase the resolution for high quality images.
- \bullet Use <code>ls -l</code> to see the difference in file size for the different formats.
- Use display to view, or gimp to view and edit all the image formats.
- Convert to eps format for inclusion in LATEX documents using: /usr/bin/convert test.jpg test.eps (we specify the whole path to make sure that we use the correct one)
- View the eps file using gv.



Animation output

- File/Save Animation saves frame images in a number of formats: jpg, tiff, png
- Use /usr/bin/convert to convert the frame images into a movie: /usr/bin/convert -quality 90% frames*.png movie.gif
- View the movie using firefox file://\$PWD/movie.gif
- Increase the resolution for high quality animations.
- In View you can toggle Animation View, which lets you control your animation. You can for instance specify which time steps to use, and how to sweep the camera during the animation (try Camera and Orbit with default settings, and click on the plus-icon). Some things work better without Parallel Projection.



Save and Load states

- The current state, including created objects and current view, can be saved for later loading, in File / Save State and Load State. This is useful if the same visualization needs to be done many times.
- Saved states can be loaded directly from paraview, so there is no need to run paraFoam.
- State files are in ASCII, so it is possible to generate or modify them externally if needed.



Multiple cases

- Multiple OpenFOAM cases can be read into paraFoam.
- For the additional cases you must generate the <case>.OpenFOAM file by hand:

touch \$FOAM_RUN/<case>/<case>.OpenFOAM

- Launch paraFoam with the first case as usual.
- Read in the additional cases in paraFoam using File/Open
- This procedure can also be used to view cases that are decomposed for parallel simulation, in order to see the domain decomposition. Then you generate a processor*.OpenFOAM file in each processor* directory. We will discuss parallel simulations later.
- This is also the procedure for multi-region cases, like conjugate heat transfer and fluid-structure interaction.



Questions

- What is the difference between paraFoam and paraview?
- How do you read in the results of the foamToVTK utility in paraFoam/paraview?
- What are the available options for the foamToVTK utility?
- What is the difference between cell- and point-based representations of fields? Which one is the one used in collocated finite volume CFD? Why is there another alternative in the post-processor?
- What is the expression in the paraview calculator to generate a vector field V = (x, y, z), where x/y/z are the Cartesian positions of each vector?
- In which positions are glyphs of vector field located by default, and how does that correspond to collocated finite volume CFD?
- \bullet What does the Linux command touch do?